

# LATITUDES

collection by Flexsteel®



1606 Sofa



1606 Love Seat



1606 Chair & Ottoman

	Height	Seat Width	Overall Width	Seat Depth	Overall Depth	Arm Height	Seat Height	Seat Cushions
<b>1606-31 Sofa</b>	37"	67"	87"	21"	40"	25"	22"	3
<b>1606-20 Love Seat</b>	37"	45"	65"	21"	40"	25"	22"	2
<b>1606-10 Chair</b>	37"	23"	44"	21"	40"	25"	22"	1
<b>1606-08 Ottoman</b>	18"		29"		22"			
<b>Cushions</b>								
Luxury Cushion (LC)								
		<b>1606-31</b>	<b>1606-20</b>	<b>1606-10</b>	<b>1606-08</b>			
		●	●	●	●			
<b>Seat Construction</b>								
Dualflex® Spring System		<b>1606-31</b>	<b>1606-20</b>	<b>1606-10</b>	<b>1606-08</b>			
		●	●	●				
Woven Webbing				●				
Attached Seat Cushion		●	●	●			●	
Loose Seat Cushion								
<b>Back Construction</b>								
Attached Back Cushion		<b>1606-31</b>	<b>1606-20</b>	<b>1606-10</b>	<b>1606-08</b>			
		●	●	●				
Semi Attached Back Cushion								
Loose Pillow Back Cushion								

## 1606 Belvedere Group

Grain / Split Leather